

## **Premise Boundary Map 1 of 5**

M4M5-LSBJ-PRW-EN-GE01-MAP-0001

#### Legend


Indicative Water Discharge Points

Construction Premise Boundary

Underground Tunnel Premise Boundary

HV transmission

Rev 16 - 17/09/2020



This map is shown for reference purposes only. Lendlease provides this information "as is" with the understanding that it is not guaranteed to be accurate, correct or complete and conclusions drawn from such information are the responsibility of the user. While every effort is made to ensure the information displayed is as accurate and current as possible, Lendlease will not be held responsible for any loss, damage or inconvenience caused as a result of reliance on such information or data.









#### **Premise Boundary Map 2 of 5**

M4M5-LSBJ-PRW-EN-GE01-MAP-0001

#### Legend


Indicative Water Discharge Points

Construction Premise Boundary

Underground Tunnel Premise Boundary

HV transmission

Rev 16 - 17/09/2020



This map is shown for reference purposes only. Lendlease provides this information "as is" with the understanding that it is not guaranteed to be accurate, correct or complete and conclusions drawn from such information are the responsibility of the user. While every effort is made to ensure the information displayed is as accurate and current as possible, Lendlease will not be held responsible for any loss, damage or inconvenience caused as a result of reliance on such information or data.









## **Premise Boundary Map 1 of 5**

M4M5-LSBJ-PRW-EN-GE01-MAP-0001

#### Legend


Indicative Water Discharge Points

Construction Premise Boundary

Underground Tunnel Premise Boundary

HV transmission

Rev 16 - 17/09/2020



This map is shown for reference purposes only. Lendlease provides this information "as is" with the understanding that it is not guaranteed to be accurate, correct or complete and conclusions drawn from such information are the responsibility of the user. While every effort is made to ensure the information displayed is as accurate and current as possible, Lendlease will not be held responsible for any loss, damage or inconvenience caused as a result of reliance on such information or data.









#### **Premise Boundary Map 4 of 5**

M4M5-LSBJ-PRW-EN-GE01-MAP-0001

#### Legend


Indicative Water Discharge Points

Construction Premise Boundary

Underground Tunnel Premise Boundary

HV transmission

Rev 16 - 17/09/2020



This map is shown for reference purposes only. Lendlease provides this information "as is" with the understanding that it is not guaranteed to be accurate, correct or complete and conclusions drawn from such information are the responsibility of the user. While every effort is made to ensure the information displayed is as accurate and current as possible, Lendlease will not be held responsible for any loss, damage or inconvenience caused as a result of reliance on such information or data.










#### **Premise Boundary Map 5 of 5**

M4M5-LSBJ-PRW-EN-GE01-MAP-0001

#### Legend

Indicative Water Discharge Points
Construction Premise Boundary
Underground Tunnel Premise Boundary
HV transmission

Rev 16 - 17/09/2020



This map is shown for reference purposes only. Lendlease provides this information "as is" with the understanding that it is not guaranteed to be accurate, correct or complete and conclusions drawn from such information are the responsibility of the user. While every effort is made to ensure the information displayed is as accurate and current as possible, Lendlease will not be held responsible for any loss, damage or inconvenience caused as a result of reliance on such information or data.





